

QUICKSTART


Puzzi 10/1 - Puzzi 10/2



-WARNING
These are only brief instructions! Please read the operating instructions accompanying the appliance prior to using or maintaining the appliance.
The non-compliance with the operating and safety instructions may lead to damage of the appliance and to risks for the operator and other persons.

Start up


1



- A Remove the cover of the wastewater tank.
- B Remove waste water tank.
- C Fill detergent solution into the fresh water reservoir. The fill level must not exceed the "MAX" mark.


Operation

1



- Turning on the Appliance**
- A Plug in the mains plug.
 - B Press the suction switch to turn on the suction turbine.
 - C Press the spray switch to switch on the spray pump.


2



- A Operate the lever on the manifold in order to spray the cleaning solution. Run across the surface to be cleaned in overlapping paths. Pull the nozzle backwards (do not push).
- B Press the suction switch to turn on the suction turbine.
- C Press the spray switch to switch on the spray pump.

Finish operation


1



- Turn off the appliance**
- A Switch off the spray and suction switches.
 - B Pull out the mains plug.


Finish operation

2




- Empty wastewater container**
- A If the dirt water reservoir is full, switch off the suction and spray switches.
 - B Remove the lid.
 - C Remove the wastewater container from the appliance and drain it.

3



- Empty the fresh water reservoir**
- A Turn off the appliance.
 - B Shortly activate the lever on bender to decrease the pressure.
 - C Separate bender from the spray/suction hose. Insert the suction hose into the fresh water reservoir.
 - D Press the suction switch to turn on the suction turbine.

4



- After each operation**
- A Flush appliance.
 - B Empty the wastewater container and clean it under running water.
 - C Empty the fresh water reservoir. Suck the remaining fresh water out of the tank.
 - D Clean the outside of the appliance with a damp cloth.
 - E Remove all water from the appliance prior to longer periods of non-use to avoid offensive odours.
 - F Allow appliance to dry thoroughly: Remove or move lid sideways.

6



- Transport**
- A For transport, place suction pipe on the carrying handle and place the spray/suction hose on top of the appliance. Wind up the mains cable and hook it into the cable hook.